

Standard Control Features:

Alarm

Automatic return to main

Door pre-opening
Emergency light in car
Light curtain
Overloading warning

Height and width of the
lifting device is closed until the door is

with doors when the
landing opening. The lock
is closed. The levers operat

www.rockwellautomation.com

OPERATION AND INTERLOCKS

The operation of the Elevator shall be simplex, selective, collective and automatic, with or without operator. The elevator operation shall be as follows:

ii) The Elevator shall not move unless the car door, landing door and all other protected openings are closed with the door closed interlocking device.

vi) The landing doors shall be interlocked so that the landing door at any floor shall not open unless the Elevator is at that floor.

vii) Push button shall be fixed in the car for holding the doors open for any length of time required.

The Elevator Panels shall have guaranteed against factory defect and faulty workmanship for a period of (12) Twelve months upon completion and turnover. Any parts found to be defective within the period, not attributed to normal wear and tear or incorrect operation shall be replaced free of charge.

WARREN

OTHER INCH

PROPOSED



REVISION

